Food Storage Multi-Unit Rack



Summary

We had a need to store 8 large 55 gallon water drums. We initially stored them vertically, which made it hard to change the water, and if we had been in an emergency situation where we needed the water, would have made it difficult to remove the water for use.

In trying to solve this problem, I ran across a website that discussed storing barrels horizontally:

http://www.theideadoor.com/index.php?option=com_content&view=article&id=252&Itemid=306

Using the information provided by that site, I devised an expansion of that idea that would serve to store our 8 barrels (actually 7), as well as potentially store our growing stockpile of #10 food storage cans.

Changes from Original Design

The original design accomodated only 2 barrels. Base on where I wanted the racks located, I would be unable to create additional shelving above them without framing in some walls. This seemed to be ineffective from a cost standpoint. As a result, I decided that the best way to utilize that dead space above the racks was to extend the racks vertically. Initially the idea was to add 3 shelves above the water barrels, to provide some storage. It was then determined that with a slight angle to the shelve, the cans on the shelves could roll forward, much like a standard can rotator. Because of the weight of the #10 cans, I didn't want the clunking around that a typical rotator entails. As such, these racks are only "rotators" in the sense that you can put new stock in the back and pull old stock from the front.

The units described here have a capacity of 3 shelves, but by elongating the vertical supports (A), you can add more shelves. Each shelf, as designed here, can hold 18 #10 cans. Our racks ended up with 4 shelves each, or 16 total shelves. We can therefore store 288 cans.

Another design change was to elongate the barrel space. The initial design called for a 21" spacer support. I added an additional 4". This was to provide greater support to the can shelves that would be used.

I also deviated from the original design in that I omitted the "feet". This was to fit more vertical space for shelves, and to provide a larger surface area to distribute the weight of the rack on the floor.

Materials

Each rack requires the following parts (not all parts have corresponding drawings):

- (A) $4 2x4x80^* vertical rack supports$
- (B) 4 2x4x27 rack facing supports
- (C) 4 2x4x25 rack depth supports
- (E) 2 − 2x4x31 ½" − rack feet

- (D) 4 27x6x3/4" (plywood) barrel support holsters
- (BASE SUPPORT) 2 24x28x3/4" (plywood) additional support
- (SHELVING) 3 35x25x3/4" (plywood) can shelving
- (FURRING) 6 1x2x35" furring strip to support can shelves
- (ROLL STOPPER) 3 1x2x24" facing strip to stop cans from rolling off shelves
- 6 24" lengths of metal drywall corner pieces this is used to create lanes for the cans
- * The length of these boards depends on the final height that you want. Our basement could only handle a roughly 80" height, however if you could handle a higher rack, then you could conceivable follow the same pattern for shelving and add an additional 1 to 2 shelves

When cutting the wood, there will unfortunately be waste. I found that I was able to cut the necessary 2x4 pieces from a total of eight 96" timbers. However, if you can get your hands on longer boards, then there will obviously be much less waste. (And in my case, I used the "waste" for other projects so it really wasn't waste.) For the plywood I found that it took 2 full 4'x8' sheets to get the necessary pieces. Again, there was some "waste."

One point to consider is that when building multiple racks, the "waste" will be much less. I built 4 at the same time when I built ours. It took roughly 2 days to build and install them all.

Construction

When constructing the racks I used 2 ½" deck screws mostly. In some places I used 1 5/8" deck screws. In many cases I also predrilled pilot holes. While this did increase the time of assembly, it ensured that minimal wood splitting would occur.

Rack Assembly

- 1. Cut all materials prior to assembly.
- 2. Cut the notches into the appropriate upright supports (A). I used a jigsaw to help with the cutting, though other tools might prove to be just as effective.
- 3. Assemble the front and back support stands by connecting 2 (A) pieces with the corresponding (B) pieces.
- 4. Screw (D) over the (B) supports. Ensure that the low point of the arc is flush with the top of the (B) support.
- 5. Attach the front and back using (C) supports.
- 6. Attach the (E) feet to the rack.
- 7. Attach the (BASE SUPPORT) pieces across the sides of the rack, generally in such a way that the center of the (BASE SUPPORT) pieces aligns with where the top of the bottom barrel would be. In my drawing I have not included these pieces, as they obscure some of the construction.
- 8. Attach (FURRING) to supports (A). I found that starting the bottom furring at 57" from the floor and then going up 7" for each additional (FURRING) was sufficient. To provide an angle, the rear

- of each (FURRING) was raise 1 ½" from level. I also started the (FURRING) about 1 ½" from the front the (A) support, to give room to add the (ROLL STOPPER).
- 9. Attach the (ROLL STOPPER) pieces. These are placed on top of the (FURRING) pieces, and placed with the 2" portion of the wood vertical.
- 10. Attach the dry wall corner pieces to the shelving and then slide the shelves into place on top of the (FURRING). There is generally no need to screw down the shelves as the weight of the #10 cans should hold the shelves down.

Installing hose bibs (faucet)

Each barrel will have two bungs, or caps. One bung should have threads in the center hole. If neither bung has threads on the inside hole, then stop here. You may purchase the correct bung from online suppliers such as Emergency Essentials or Honeyville.

- 1. Remove the center backing of the bung. This must be done on the bung with threads in the center. Be careful not to damage or remove any of the existing threads.
- 2. Install the bung into the barrel. No Teflon tape should be used, as the bung should have a rubber gasket around it. The bung should be tightened with a bung wrench. This can be purchased for a few dollars from the above mentioned suppliers.
- 3. Screw in the ¾" hose bib into the bung, having wrapped the hose bib threads with Teflon tape. Tighten the bib until it is pointing down
 - a. I used right angle bibs on the upper barrels and obtuse (45 degree) bibs on the bottom barrels, for each of attacking a hose. If I did it again, I'd have used obtuse bibs on all barrels.
- 4. Fill the barrel with water. Water should be rotated regularly (6 to 9 months), in most cases.

Notes on Durability

In calculating how much this entire rack would weigh, and if our cement basement would support it, we used the following assumptions:

- Cured concrete strength: 4000 pounds per square inch (psi)
- Total weight of a loaded rack: 1300 lbs
- Surface area contacting cement (roughly): 156 sq inches

This all resulted in an average of 9 psi, well within the range that our cement could handle. As for the wood itself, I let it cure for about a month in our dry Colorado climate. This helped to remove all moisture from the wood. The racks were assembled in the fall of 2009, and as of this writing (Spring 2011) we have had no problems.

I've seen reports of similar racks and the barrels failing due to the weight of the water putting pressure on the side of the barrel. Our barrels have not had that problem. If that is a problem, additional support could easily be added horizontally across each barrel area.



Figure 1

All four racks side by side with 7 barrels installed. At this point the barrels do not have water in them. Note how the shelves are angled, and how the barrels fit into the holsters.



Figure 2

Close up of can shelf, including ROLL STOPPER and drywall corner pieces used to define lanes for can rows. I used a staple gun to tack down the corner pieces.



Figure 3

Close up of hose bib installation. Note the use of Teflon tape where the bib was screwed into the bung cap. Be careful with the bungs, as the can be cracked if the bib is tightened too much.




Figure 4

Showing the layout of the shelves, including placement of the ROLL STOPPER. When cans are placed in each lane the bottom of the next shelf up should help the can not roll out the side of the shelf. Note that at the top of the unit an small 2x1/2" furring strip was added to the side to ensure the top cans do not roll out the side of the top shelf.




Figure 5


Fully assembled and loaded racks. Since installing the racks, I have added white board strips to the front of each row. On these strips we've written what each row contains and how many are in that row. Ideally we'd also write the date of the oldest item in that row.







































© 2011 waterstoragerack.blogspot.com





© 2011 waterstoragerack.blogspot.com



© 2011 waterstoragerack.blogspot.com

02/22/2011

